



NOTES:

1. REFER TO FILTREXX® VEGETATED RETAINING WALL DETAIL FOR ADDITIONAL INFORMATION.
2. POST FOOTING: PLACE SONOTUBE BEHIND DURING CONSTRUCTION AS REQUIRED.
3. ALL FOOTING TO BE APPROVED BY ENGINEER.
4. POST BACKFILL TO BE APPROVED BY ENGINEER AND COMPACTED AS REQUIRED.
5. FINAL FENCE DESIGN TO TAKE WIND LOADING CONDITIONS INTO ACCOUNT.